


PRODUCT MANUAL

PRO HEAT BLOW TORCH KIT

Part No. 10000594



PRO HEAT BLOW TORCH KIT

Part No. 10000594

FEATURES

- Piezo Ignition
- Easy bayonet push and rotate
- Adjustable Flame with on/off control
- 360° with Anti flare after 15 seconds
- Standard flame
- Use for Cooking, Heating, Soft Soldering, Hobby, Camping, DIY, Workshop, Heat shrinking and Jewellery/Art

SPECIFICATIONS

Consumption: 72.70 g/hr
Burning time: 165 min
Flame length: 180 mm
Gas type: Butane

• Connection type: Bayonet fitting

CONTENTS

- Pro heat blow torch
- Butane cartridge 220 g bayonet fitting


OPERATION

This Pro Heat Blow Torch should only be used with a Butane gas nonrefillable cartridge, with bayonet fitting, certified to EN417 or DOT2P.


It may be hazardous to attempt to fit other types of gas containers.

TO ASSEMBLE

- 1. Remove red warning label from torch connection point, prior to use.
- 2. Ensure the flame control knob is turned off (OFF) fully clockwise.
- 3. Keep the cartridge in an upright position and place the torch valve on top of the cartridge push type fitting making sure the locating lug on the valve lines up with the locating lug on the cartridge.



4. Holding the torch, push down slightly and then turn clockwise, until it can turn no further. **CAUTION** Do not over tighten.




IMPORTANT: Always check for leaks using a leak detection spray or soapy water before ignition.

CHECKING FOR GAS LEAKS

Spray Gas Leak Detection Spray (211634) around seal and check for bubbles. **DO NOT USE IF YOU SMELL GAS OR SEE BUBBLES.**

If you smell gas or see bubbles, the torch is not correctly attached to the gas cartridge. **DO NOT IGNITE.** Remove the blow torch from the gas cartridge and re-attempt connection.



TO IGNITE

To avoid injury or damage always point the burner away from your body, other persons or objects and any flammable or combustible materials.

- 1. Ensure the Flame Control Knob is turned fully clockwise (OFF).
- Turn the Flame Control Knob a quarter turn counter-clockwise (ON) to enable the gas to flow.
- Press the trigger to ignite the flowing gas. This torch can be used in an inverted position after 15 seconds of use.

TO EXTINGUISH

- 1. Turn the Adjustable Flame Control off (OFF) fully clockwise.
- CAUTION The burner becomes extremely hot during and after operation.
 Care must be taken to avoid accidental burns.
- ALLOW THE TORCH TO COOL

TO DISASSEMBLE

- 1. Follow the **EXTINGUISH** instructions.
- 2. Ensure burner has cooled properly.
- **3.** Gently turn the torch counter-clockwise. Remove the torch from the cartridge.

STORAGE

- 1. REFER to "HANDLING & STORAGE" details on the gas cartridge label.
- 2. ALWAYS detach torch from cartridge when not in use.
- DO NOT store near source of heat, in a vehicle or in a room used for habitation.
- 4. STORE the torch and cartridge in a safe dry place.
- DO NOT breathe gas, fumes, vapour or spray. If inhaled, move the person to a fresh air environment.
- 6. AVOID contact with eyes or skin. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.

WARNING

- ENSURE THAT YOU READ AND FULLY UNDERSTAND THE INSTRUCTIONS AND PRODUCT BEFORE USE.
- DO NOT try to use this tool without first reading and understanding the instructions.
- FAILURE to comply with these instructions and warnings may result in damage to property, personal injury or death.
- ALWAYS inspect the torch before use to ensure it is in good working order.
- ALWAYS detach torch from cartridge when not in use.
- DO NOT attempt to use the torch if it is leaking, damaged or malfunctioning.
- ONLY use in well ventilated areas.
- CARBON MONOXIDE HAZARD This torch can produce carbon monoxide which has no odour. Using it in an enclosed space, may cause death.
- NEVER leave the torch once lit. Extinguish the torch first ensuring it is completely out and safe before leaving unattended.
- CAUTION accessible parts may be very hot during and after operation.
 Care must be taken to avoid accidental burns.
- ENSURE flame is completely out after use.
- PROTECT from direct sunlight.
- DO NOT expose to temperature above 40°C / 104°F.
- KEEP out of reach of children.
- TO AVOID injury or damage only ignite the torch when clear of face, hands, clothing or combustible materials.
- ALWAYS inspect your environment before igniting to ensure the area is clear of any potential ignition sources or hazards.
- CONTAINS flammable gas under pressure.
- DO NOT disassemble, puncture or incinerate cartridge after use.
 Cartridges must be stored and handled in accordance with AS1596.
- CAUTION for maximum protection, always wear safety goggles, gloves and other appropriate safety equipment.
- AVOID contact with eyes or skin. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.

MAINTENANCE/SERVICING

Serviceable components: N/A Servicing instructions: N/A



CAUTION: For maximum protection, always wear safety goggles, gloves or other appropriate equipment

