



## PRODUCT MANUAL HANDY MICRO TORCH

PART NO. 211234



### FEATURES

- Piezo ignition
- Fully controllable flame adjustment allows you to regulate the heat for a range of heating jobs
- Trigger lock for continuous use
- Refillable butane gas chamber with sight window to monitor fuel level
- Great for the kitchen, workshop and tool box
- Use in conjunction with Butane Cartridge 70 g (10000602) & 200 g (10000603)

### SPECIFICATIONS

- **Consumption:** 10 g/hr
- **Fuel storage size:** 15 g
- **Burning time:** 90 min
- **Flame length:** 65 mm

### FILLING/ REFILLING GAS

1. Ensure continuous flame switch is in off position and torch has cooled down
2. Hold torch in an upside-down position
3. Insert the butane cartridge refill nozzle into the refilling valve and push down
4. Stop refilling when gas starts to overflow

### TO IGNITE

1. Push the lock switch down
2. Depress trigger
3. Push continuous flame switch to upper position
4. Adjust flame level with the flame adjustment lever
  - A) + to increase
  - A) - to decrease

### TO EXTINGUISH

1. Slide the continuous flame switch to the lower position.

### WARNING

- To avoid injury or damage only ignite the torch when clear of face, hand, clothing or combustible materials
- The burner becomes extremely hot during and after operation. Care must be taken to avoid accidental burns
- Ensure the flame is completely out after use
- Protect from direct sunlight. Do not expose to temperature above 50°C/120°F
- Contains flammable gas under pressure. Do not disassemble, puncture or incinerate after use

**TORCH IS SUPPLIED WITHOUT GAS. TORCH REQUIRES FILLING BEFORE USE. USE WITH TRADEFLAME BUTANE GAS REFILL 70 G (10000602) & 200 G (10000603)**



**CAUTION:** For maximum protection, always wear safety goggles, gloves or other appropriate equipment