




MICRO JET BUTANE TORCH

PRODUCT MANUAL

PART NO. 411678



TORCH IS SUPPLIED WITHOUT GAS. TORCH REQUIRES FILLING BEFORE USE. USE WITH TRADEFLAME BUTANE GAS REFILL 70G (10000602 / 326602) & 200G (10000603 / 326603)

CAUTION: For maximum protection, always wear safety goggles, gloves or other appropriate equipment

IMPORTANT: READ THESE INSTRUCTIONS FOR USE CAREFULLY. FAMILIARISE YOURSELF WITH THE APPLIANCE BEFORE CONNECTING IT TO ITS GAS CONTAINER. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

FEATURES

- **Gas:** Suitable for use with Butane (sold separately)
- **Effortless ignition:** Ditch the matches! A simple trigger click sparks the flame instantly
- **Compact powerhouse:** Lightweight and portable, this torch goes wherever your projects take you

TO IGNITE

1. Unlock safety cap by pressing the unlock button.
2. While gently pressing the unlock button, slowly depress the ignition button.

TO EXTINGUISH

1. Release the ignition button. Torch will shut off immediately.
2. Close the flame nozzle cover.

FILLING / REFILLING GAS

1. Ensure safety cap is in place.
2. Shake gas cartridge well.
3. Insert cartridge nozzle vertically into gas refill valve at the base of the Micro Jet Butane Torch. Press firmly to start gas flow. **DO NOT OVERFILL.**
4. Refill in a well-ventilated area and away from fire or ignition sources.
5. Allow 2 – 3 seconds to refill torch.
6. Before igniting, allow 90 seconds for gas to stabilise.

TROUBLESHOOTING

PROBLEM

- Does not ignite

PROBABLE CAUSE

- Fuel empty

CORRECTION

- Refill with TradeFlame Butane Gas 70g (10000602 / 326602) or 200g (10000603 / 326603)



TURBO BLOW TORCH KIT

PRODUCT MANUAL

PART NO. 411067

WARNING

This appliance shall only be used with TradeFlame Butane.

IT MAY BE HAZARDOUS TO ATTEMPT TO FIT OTHER TYPES OF GAS CONTAINERS.

THE APPLIANCE IS NOT SUITABLE FOR INSTALLATION OR CONNECTION TO A RETICULATED GAS SUPPLY.

ONLY USE IN WELL-VENTILATED AREAS.

CARBON MONOXIDE HAZARD - USING THIS APPLIANCE IN AN ENCLOSED SPACE MAY CAUSE DEATH. DO NOT USE IN CARAVANS, TENTS, MARINE CRAFT, CARS, MOBILE HOMES OR SIMILAR LOCATIONS.

CAUTION: Accessible parts may be very hot. Keep young children away.

KEEP OUT OF REACH OF CHILDREN.

SAFETY INFORMATION

- Inspect the appliance regularly for signs of wear, leaks or incorrect operation.
- Do not modify this appliance.
- Ensure all packaging is removed prior to use.
- Check that seals are in place and in good condition.
- Do not use this appliance if it has damaged or worn seals.
- Do not use the appliance if it is leaking, damaged or does not operate properly.
- Refill in a well-ventilated location, preferably outside, away from people and any source of ignition, such as naked flames, pilot flame, electric heaters/equipment.
- To avoid injury or damage, only ignite the torch when clear of face, hands, clothing or combustible materials.
- Always inspect your environment before igniting to ensure the area is clear of any potential ignition sources or hazards.
- The burner becomes extremely hot during and after operation. Care must be taken to avoid accidental burns.
- This appliance must be operated away from any flammable material or surfaces and materials.
- Never leave the torch unattended once lit. Extinguish the torch first ensuring it is completely out and safe before leaving unattended.
- Protect from direct sunlight. Do not expose to temperature above 50°C/120°F.
- Do not breathe gas, fumes, vapour or spray. If inhaled, move the person to a fresh air environment.
- For maximum protection, always wear safety goggles, gloves or other appropriate equipment.
- Avoid contact with eyes or skin. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.