

Tradeflame

ULTRA30™

LASTS LONGER • BURNS HOTTER

Disposable

453.6g / 16oz

DANGER HIGHLY FLAMMABLE GAS

Misuse can cause severe injury.
Always read the label / manual and leak-test every connection before lighting the appliance.



IMPORTANT - ALWAYS CHECK FOR GAS LEAKS BY SPRAYING GAS LEAK DETECTION SPRAY OR FOAM ON ALL CONNECTIONS PRIOR TO USE



DANGER

- EXTREMELY FLAMMABLE GAS.
- CONTAINS GAS UNDER PRESSURE; MAY EXPLODE IF HEATED.
- KEEP AWAY FROM HEAT / SPARKS / OPEN FLAMES/HOT SURFACES. NO SMOKING.
- LEAKING GAS FIRE: DO NOT EXTINGUISH, UNLESS LEAK CAN BE STOPPED SAFELY.
- ELIMINATE ALL IGNITION SOURCES IF SAFE TO DO SO.
- PROTECT FROM SUNLIGHT. STORE IN A WELL-VENTILATED PLACE.
- FOLLOW INSTRUCTIONS SUPPLIED WITH APPLIANCES.
- USE ONLY WITH TRADEFLAME TORCHES DESIGNED FOR ULTRA30™ GAS, AS INDICATED BY A MULTI-FUEL LOGO ON TORCH. NOT COMPATIBLE WITH OTHER BRANDED TORCHES OR APPLIANCES.
- NEVER USE WITH STANDARD PROPANE APPLIANCES SUCH AS LANTERNS, STOVES, TORCHES, ETC.
- KEEP OUT OF REACH OF CHILDREN.
- REFER TO THE SDS FOR FIRST AID MEASURES, FIRE FIGHTING MEASURES, ACCIDENTAL RELEASE MEASURES AND HANDLING AND STORAGE.

SPECIFICATIONS

- **Gas:** Propane $\geq 22\%$ (74-98-6)
Propylene $\geq 44\%$ (115-07-01)
Dimethyl Ether $\geq 44\%$ (115-10-6)
- **Gas fitting:** BOM fitting
- **Fuel cartridge size:** 453.6g / 16oz

INSTRUCTIONS:

BEFORE USE

1. Check cartridge and torch seals. Never use with damaged or missing seals. Discard cartridge if dirt or rust particles are in valve area.
2. Turn off torch.
3. Hold cartridge upright while attaching torch.
4. Attach cartridge outdoors away from pilot lights, flames, sparks and other ignition sources. They can ignite leaking gas.
5. Hand tighten only. Never use tools to tighten. Over-tightening can damage seals.
6. Check for leaks. Spray **Tradeflame Leak Detection Spray (211634)** or **Tradeflame Leak Detection Foam (400023)** on connections. Look for bubbles. Listen for hiss of escaping gas. Feel for extreme cold. Smell for rotten egg odour. Do not use if leaking.
7. Read and follow torch instructions.

DURING USE

1. Use upright to prevent flare-ups or flashes. Never drop or throw cartridge.
2. If torch sputters or flares up, turn cartridge upright and turn off torch. Vent area to remove unburned gas. Slowly turn on. After hearing slight hiss, re-light.
3. Never use near pilot lights, flames, sparks, and other ignition sources. They can ignite leaking gas.

AFTER USE

1. Turn off torch. Let cool.
2. Detach torch when not in use.
3. Detach outdoors away from pilot lights, flames, sparks, and other ignition sources. They can ignite leaking gas.
4. Replace cap to keep valve clean.
5. Store the gas cartridge outdoors in a well ventilated area out of the reach of children. Any indoor storage area shall comply with AS/NZS 1596.

-20°C to +65°C

**DO NOT REMOVE OR
DEFACE THIS LABEL**



UN3161

DO NOT REFILL

CN NBRK [BATCH NO. SEE BASE]

PH23BAR 0.95L

P1266
Tr2880 EN ISO 11118:2015 GB P RJ



*13% more gas, 12% longer burn time and 6% hotter compared to propane
MAPP® is a registered Trademark of the Linde Group

Tradeflame.com

Distributed by
TRADEPEM INDUSTRIAL PTY LTD